



# Power Telematics ModPro Readings

## Generac G Panel

| Alarms                                 |                        |                       |
|----------------------------------------|------------------------|-----------------------|
| Generator On/Running                   | Common Shutdown        | Overspeed Alarm       |
| Extended Run<br>90min/4/8/12/24+ hours | Common Warning         | Over Crank Alarm      |
| Not In Auto                            | Battery Voltage High   | E Stop Active         |
| Not in Auto 4+ hours                   | Battery Voltage Low    | High Fuel Level Alarm |
| Low Fuel Pressure                      | High Engine Temp Alarm | Low Fuel Level Alarm  |
| Battery Charger Fault                  | High Engine Temp Warn  | Low Coolant Level     |
| Gen Supplying Load                     | Low Engine Temp Alarm  | Rupture Basin Alarm   |
| Utility Supplying Load                 | Low Oil Pressure Alarm | Remote Start Active   |
| Common Fault                           | Low Oil Pressure Warn  |                       |

| Analog Values           |                   |                 |
|-------------------------|-------------------|-----------------|
| Oil Temp                | Gen Avg Volts L-L | Gen Volts L2-L3 |
| Coolant Temp            | Gen Avg Current   | Gen Volts L3-L1 |
| Oil Pressure            | Gen Avg Voltage   | Gen Frequency   |
| Battery VDC             | Gen Current L1    | Gen Total KW    |
| RPM                     | Gen Current L2    | Gen Total PF    |
| Fuel Level              | Gen Current L3    | Engine Hours    |
| Battery Charger Current | Gen Volts L1-L2   |                 |

\*All value availability is determined by individual Controller Programming and Options.